

# IBC ALARM - LOW LEVEL (ILP)



## 1. CONNECT BATTERY

- Open the cover and snap the battery inside into the battery clip. Replace cover.
- On units powered by AC adapter, plug in the power jack.

## 2. CONNECT TUBING

The compression fitting will work on hard or soft tubing.

- Cut tubing squarely. (Remove burrs if hard tubing)
- Insert tubing through the nut all the way to the back.
- Turn the nut hand tight.



## 3. ADJUST DEPTH

Loosen thumb screw to set the correct depth.

## 4. ELECTRONICS

- The default behavior provides for an alarm when level is low. Pressing the green silence/test button will silence the alarm. (but the LED continues to blink) The buzzer will sound again after 30 minutes if the level is still not corrected.
- Other behaviors can be selected with the jumpers. See separate instruction sheet on the "Silencing Button".
- The circuit board will provide an alert when battery power is getting low. (a short 5 second alarm every 30 seconds)

## 5. SERVICE

The screen in the suction pipe can be accessed for cleaning if necessary by unscrewing the retainer with a coin..



ADJUSTING DEPTH

Sep 29, 2017